


HIDDEN TECHNOLOGY – TECHNOLOGY BECOMES INVISIBLE.

MIRROR TV ASCENT SMM 550

ASCENT SERIES

STANDARD PRODUCTS



- Intergrated Loudspeaker
- High Brightness screen
- Ascent[™] Technology
- Touchpad, 5 Keys
- Easy to install

ASCENT [™] TECHNOLOGY

With ASCENT [™] we raised the experience of using a Mirror TV to the highest degree. To do that, we created a fully-fledged vanity mirror and an all new 55" TV – in one device. The breakthrough ASCENT TM technology lets you easily transform your TV picture inside the mirror from 16,5" to 55", or the other way around. This allows you watching a movie in brilliant full size mode, while one touch brings back your vanity mirror with a 16,5" picture. Where this 16,5" picture is positioned on the mirror is decided by yourself, four preset positions are available. With MAGIC MIRROR as part of this product, ad notam delivers the highest standard of picture quality when turned on, while when turned off, the TV picture completely disappears behind the MAGIC MIRROR, leaving back nothing more than your vanity mirror.

ad notam

HIDDEN TECHNOLOGY – TECHNOLOGY BECOMES INVISIBLE.

ASCENT SERIES

MIRROR TV – ASCENT SMM 550

GENERAL INFORMATION				
Installation method	On-Wall Installation			
Product Dimensions	1320 W x 930 H x 60 D mm 51.97" W x 36.61" H x 2.36" D inch			
Product Weight	45 kg 99.33 lbs			
Product Usage	For In-Door Use only			
Operating Temperature	5° to 50° Celcius (41° to 122° Fahrenheit)			
Humidity	20% - 80%			
HS Code	85 28 59 31			
Packaging type	Carton Box			
Packaging dimensions	1520 W x 1130 H x 280 D mm 59.84" W x 44.49" H x 11.02" D inch			
Packaging Gross Volume Weight	59,98 kg 132.37 lbs			

CE




ad notam[®]

HIDDEN TECHNOLOGY – TECHNOLOGY BECOMES INVISIBLE.



MIRROR TV-ASCENT SMM 550

SCREEN				
		-		
Display type	TFT Thin Film Transistor			
Backlight	LED			
Screen Diagonale	1387 mm (54.6'')			
Picture Format	16:9			
Physical Resolution	1920 x 1080			
Viewing Angle	Horizontal: Typical (Total) 178° (Left: 89° / Right: 89°) Vertical: Typical (Total) 178° (Up: 89° / Down: 89°)			
Brightness ¹	450 cd/m2			
Contrast	Typical: 1300:1			
Response Time	9 ms			
Video Inputs	HDMI 1.3	Зx	HDMI terminal	480i, 480p, 576i, 576p, 720i, 720p, 1080i, 1080p
	Component (YPbPr / YCbCr)	1x	RCA terminal, green (Y), blue (Pb), red (Pr)	720p, 1080i, 1080p
Audio Inputs	Line Level Input	1x	RCA terminal, white (L), red (R)
Other Inputs	USB	1x	USB terminal	Software Update, Media Player
Audio Outputs	Speaker Output	1x	Phoenix Clip 4pin	2 x 8W RMS @ 8 Ohm per channel
Other Outputs	IR Output (Infrared - Cable)	1x	Mini Jack 3.5 mm	
	IR Output (Infrared - LED)	1x	Mini Jack 2.5 mm	
Media Player	Audio		MP3, AAC, M4A/AAC, WMA	
	Picture		JPEG/JPG, BMP, PNG	
	Video		AVI, MPG, DAT, MOV/MKV	
OSD Language	Deutsch, English, Espanol, Francais, Italiano, Portugues, Chinese			
Power	AC 110-240V (50/60Hz) Standby: 0.8W / 33mA / Default: 111W / 4.62A / Maximum: 157W / 6.57A			
Certification	UL 60950-1 , CAN / CSA 22.2 - 60950-1, CB, FCC, EN 60950-1, EMC 55022, EN 6100-3-2			





1 Value might vary slightly dependent on your selected glass/ mirror type.

ad notam®

HIDDEN TECHNOLOGY – TECHNOLOGY BECOMES INVISIBLE.

ASCENT SERIES

MIRROR TV – ASCENT SMM 550

GLASS & MIRROR			
Туре	Silver Magic Mirror		
Surface	Float		
Tint	Silver		
Reflection	40% +/- 5		
Transmission of screen image area	60% +/- 5		
Reflection of screen image area	40% +/- 5		

Туре	Pair				
Rated power	10W, max. power 20W				
Impedance	8 Ohm				
Sensitivity	85 dB				
Frequency response	60 - 20000 Hz				
TOUCHPAD					
Technology	Capacitive				
Number of Keys	5				
Functions	 ON/OFF Volume Up Volume Down Volume Mute Scale 				
IMAGE SWITCH					
Full Screen	55"				
Small Screen	16.5"				
Presets/Positions	4				
OPTIONAL ACCESSORIES					
Set Top Box IPTV					
Set Top Box T /S2					
Digital Signage Player Hardware					
Waterproof Remote Control					
IR Emitter Cable					
IR Loop Through Cable					